



KICK-OUT FLASHING
City of Proctor
Building Safety Division
218-624-3641
www.proctormn.gov



This handout is intended only as a guide and is based in part on the 2015 Minnesota State Building Code, City of Proctor ordinances, and good building practice. While every attempt has been made to insure the correctness of this handout, no guarantees are made to its accuracy or completeness. Responsibility for compliance with applicable codes and ordinances falls on the owner or contractor. For specific questions regarding code requirements, refer to the applicable codes or contact your local Building Safety Division.

KICK-OUT FLASHING

The following is an excerpt from the 2007 Minnesota Residential Code:

“R903.2.2 Kick-out flashing/diverter. A kick-out flashing shall be installed where the lower portion of a sloped roof stops within the plane of an intersecting wall cladding, in such a manner as to divert or kick out water away from the assembly.”

Below are examples of the installation of kick-out flashing. Kick-out flashing may be either factory made or field fabricated. Kick-out flashing is typically required when a home is re-sided but not re-roofed.

